

# Nokia Music User Guide

### Get started with Nokia Music

#### About Nokia Music


Select  > **Nokia Music**.

With the Nokia Music client, you can discover new music and download songs to your phone.

**Tip:** You can manage your music collection with my music.

The services, features, and content may not be available in all countries and may be provided only in selected languages. The service, operations, and some features may also be dependent on the network, the compatibility of the phones or devices used, and the content formats supported.

#### Sign in to Nokia Music

Select  > **Nokia Music** > **settings** > **account** > **sign in**, then type in your Nokia account username and password.

#### Sign out

Select **settings** > **sign out**.

#### Create an account

Select **settings** > **account** > **sign in** > **I don't have a Nokia account**, then follow the instructions shown on your phone.

If you stop browsing Nokia Music, you are automatically signed out after four hours.

### Stream music with Nokia Mix Radio

The easiest way to check out new artists and songs in different genres is to stream music with Nokia Mix Radio.

Select  > **Nokia Music** > **mix radio**.

Select the mix you want to play.

#### Pause or resume music

Select  or .

#### Skip to the next song

Select .

The number of times you can skip a song may be limited.

### Make a mix available offline

Select and hold the mix.

You can only have a certain number of mixes offline at a time. To delete a saved mix, select and hold the mix, then select **delete**.

Mixes may be available offline for only a limited period of time.

### Download the current song

Select .

**Tip:** To pin your favourite mix to your start screen, select and hold the mix, then select **pin to start**.




**Tip:** Where available, use a Wi-Fi connection to stream music from Nokia Music. For further instructions on how to connect to the internet, see the user guide for your phone.

Downloading and streaming music and other content may involve transfer of large amounts of data through your service provider's network. For info about data transmission charges, contact your network service provider.

This service may not be available in all countries or regions.


## Get recommendations with mix radio

With Nokia Mix Radio, you can create personalised mixes to get recommendations for music that's similar to your favourite artists.

- 1 Select  > **Nokia Music** > **mix radio**.
- 2 Swipe to **create**.
- 3 Select .
- 4 Write an artist name – you can add up to three names.
- 5 Select  to create a mix based on the selected artists.

## Personalise your mix radio

You can create a music profile to listen to genre mixes that have been tailored to your taste. Your profile is compiled automatically from the music you have on your computer.

- 1 Select  > **Nokia Music** > **mix radio**.
- 2 Swipe to **personalise**, then select **How does it work?**.

## 4 Sync music between your phone and PC

- 3 On your computer, go to the web address shown on your phone, then follow the instructions shown on the website to create your profile.
- 4 On your phone, select **personalise > get my music profile** and the genre you want to listen to.

**Tip:** Scroll down past the images to see all of your genres.

This service may not be available in all countries or regions.

### Sync music between your phone and PC

Do you have music on your PC that you want to listen to on your phone? Use the Zune PC app to sync music between your phone and PC.



- 1 Connect your phone to a compatible computer with a compatible USB cable.
- 2 On your computer, open Zune, then drag and drop songs onto the phone icon. For more info, see the Zune help.

You cannot sync DRM-protected music with Zune.

Download the latest version of Zune from [www.zune.net](http://www.zune.net).

### Got Nokia Music Unlimited?

#### Start using Nokia Music Unlimited on your phone

With your Nokia Music Unlimited phone, you can start downloading music to your phone right away.

Select **⌵ > Nokia Music > store**

Select **settings > activate subscription**. If asked, type in your Nokia account username and password.

You need a Nokia account to use Nokia Music Unlimited. If you have a Nokia account, sign in. If you don't have an account yet, create one.

Once you have started to use your phone, you may receive text messages from Nokia. Keep the text messages as they contain important info.


You can only have one Nokia Music Unlimited subscription associated with your Nokia account. If you sign in and activate a subscription on a different phone, you can no longer use Nokia Music on your first phone.

When you have a Nokia Music Unlimited membership associated with your Nokia account, do not close the account. If you do, you are not able to use your membership anymore.

### **Check the status of your subscription**

Select settings.

### **Download music from Nokia Music Unlimited**

- 1 Select  > **Nokia Music** > store.
- 2 Sign in to Nokia Music.
- 3 Select what you want to download.
- 4 Select **download**. If asked, confirm the selection.

Downloading and streaming music and other content may involve transfer of large amounts of data through your service provider's network. For info about data transmission charges, contact your network service provider.

**Tip:** Where available, use a Wi-Fi connection to download music from Nokia Music. For further instructions on how to connect to the internet, see the user guide on your phone.

The downloaded songs are saved on the memory card or mass memory of your phone.

### **Change your registered phone**

Want to use another phone with your Nokia Music Unlimited membership? You can change it once every 90 days. The new phone must also be compatible with Nokia Music Unlimited.

- 1 Access Nokia Music on your new phone.
- 2 Sign in with your username and password. The service recognises that the phone is not your registered phone, and offers you the option to change the phone.  
If the new phone has an unused Nokia Music Unlimited subscription, the two subscriptions are merged.

The phone is now registered to your account, and you can start downloading songs.

After your Nokia Music Unlimited membership has ended, you will not be able to download new songs through the service.

If you have problems with your subscription, see the FAQ or contact Nokia Care.